

Big Feet



To remove the wheels, jack up the *RICKSHAW DOLLY*®. Hold the wheel in place and loosen the wheel bolt with a Size 8 Allen wrench.

Remove the wheel bolt from the guide and push the wheel out of the brake caliper. Block the brake piston using the retainer lock.

size	air pressure
21"	max 0,8 bar/max 11,6 psi


Big Feet



Bring the Big Feet in position and screw the wheel bolt in.

Wheel arm/wheel standard position:
Middle horizontal, second vertical row.

Please note:
Manual, Operation and assembly instructions/
6. main wheel unit



Not for gravel and other sharp-edged surfaces!



Hans
ellner
Works

UG (Haftungsbeschränkt)